



DREAM IT. DESIGN IT. PUBLISH IT.

Media Player Setup and Activation Instructions

What's Included



DigitalB Media Player



Wireless
Input Device



HDMI Cable



WIFI Antenna



Power Adaptor A & B



Wall Bracket

What You'll Need

- 1080p HD Display or TV
- Tools to Install Wall Bracket

How to Setup Your Device to Your TV

Step 1

Connect one end of the HDMI cable to your DigitalB and the other end into an HDMI port on your TV.

Step 2

Connect your A and B power cords. Then, connect one end into your DigitalB and the other into a wall outlet.



HDMI



Power Cable



Step 3

Attach your provided wall bracket to mount your DigitalB.

Attach to wall with (4) screws. (Use anchors if needed)




Device should be inserted into bracket label facing out

Step 4

Connect your wireless USB input device's receiver to your DigitalB.



Pull USB dongle from back of input device and insert into device USB port



Note: For best reception/connectivity, connect USB dongle into front USB port on device.

Step 5

Connect your WIFI antenna to your DigitalB.



Screw WIFI antenna into device



Step 6

Power on your display and select the proper HDMI port through your display's settings. Then power on your DigitalB Media Player by pressing the power button. Use your wireless input device provided to go through the DigitalB Media Player setup.



USB Charging Cable




If you need to charge your device, plug the mini connector into input device and USB connector into any device with a USB port.

DigitalB Media Player Setup

To setup your DigitalB device follow the illustration steps below.


1. Get Started



1. Click

Get Started


2. Network Setup



Click




or



WIFI Setup

Select your WIFI name, enter your password, then click connect.




LAN Setup


LAN connection will automatically use the Auto IP Address setting. If manual network settings are required, enter the appropriate information in the text fields and click the save button.

3. Device Run Time Schedule


Once you have connect your device to the internet, your device will be AirPlay® ready. Click **Next** to continue setup of your DigitalB Media Player.




4. Screen Orientation



Click





or



to change your screen's orientation to landscape (default setting) or portrait.

5. Device Run Time Schedule


To set your DigitalB Media Player's run time schedule first select your time zone. Next select the time for your device to sleep and wake. Then click **Next** →



6. Activate Your Device

Enter your activation code found in your DigitalB Account Activation notice email. Once activation code has been entered click to begin displaying your content. **Activate**

If you don't have your activation code, please contact DigitalB customer service at (248) 306-0677.



7. Create Your DigitalB User Account

Visit www.digitalb.net/activation_login.aspx. Enter your activation code, click activate, then follow the online instructions.

Notes

- Use your TV or Display remote to power it off
- Use your TV or Display remote to adjust volume
- For further information and FAQs, please visit support.digitalb.net

